



## Highlights

- Flexible, open-architecture design is scalable for future computer equipment upgrades
- Comfortable, ergonomic data entry—work sitting or standing with ergonomic 20" (51 cm) lift adjustment
- Five-inch (13 cm) LCD height adjustment ergonomically accommodates average range of users
- Extremely easy-to-clean design promotes infection control
- Barcode scanner holder provides easy access to hand-held scanner
- Extends/retracts LCD and keyboard up to 39" (99 cm); fold equipment back out of the way when not in use. With the keyboard folded up, total system depth is as little as 12" (30.5 cm)
- Ergonomic negative-tilt keyboard tray with left or right mouse tray ensures wrists remain in a neutral position during data entry
- Maintains the relative position of screen and keyboard throughout full range of motion
- Clean, concealed and neat routing of cables through the expansive cable management system

# Ergotron®

## StyleView® HD Combo



## Wall-mount workstation with single-motion adjustment

Provides sit-to-stand vertical adjustment and articulation that maximizes patient-caregiver interaction. Maintains the relative position of the screen throughout the full range of motion. Keyboard tray extends up to 39" (99 cm) and folds up 90° for total clearance of approximately 12" (30.5 cm). Optional 18" (46 cm) extender arm increases range of motion for even greater reach.



- ① Integrated keyboard tray with right/left mouse tray
- ② Fold-down keyboard tray with built-in mouse pad surface
- ③ Adjustable negative-tilt keyboard tray (0° to -10°)
- ④ Integrated mouse and barcode scanner holders provide easy access
- ⑤ Optional 18" (46 cm) extender arm (45-219-216 or 45-219-200) increases range of motion for even greater reach
- ⑥ Patented CF lift-and-pivot motion technology provides premium 5" (13 cm) LCD height adjustment, portrait-to-landscape rotation and 30° tilt
- ⑦ Durable, easy-to-clean exterior composed of aluminum, high-grade plastic and powder-coated painted steel



LCD Size	Weight Capacity*	Lift**	Tilt†	Pan	Rotation	VESA
≤ 24"	see below	20" 51 cm	30°	360°	90° P/L	MIS-D

\*Weight Capacity: display = 6–18 lbs (2.7–8.2 kg); keyboard, mouse and barcode scanner = 5 lbs (2.3 kg)

\*\*Lift Range: LCD and keyboard adjusts 15" (38 cm) in tandem; LCD adjusts 5" (13 cm) independently; maximum LCD height adjustment = 20" (51 cm)

† Monitor up/down tilt = +25°/-5°

Product Name	StyleView HD Combo
Part Numbers	45-215-216 (white) 45-215-200 (black)
Product Includes	HD Combo Arm, wall mount bracket, height-adjustable LCD mount, wrist rest, scanner and mouse holder, integrated keyboard tray with left/right mouse tray, handle, manual, VESA-monitor mounting kit, cable ties
Shipping Dimensions	12"H x 20"W x 24"D (305 x 508 x 610 mm)
Shipping Weight	25 lbs (11.3 kg)
Warranty	5 years
Weight Capacity*	Display = 6–18 lbs (2.7–8.2 kg); keyboard, mouse and barcode scanner = 5 lbs (2.3 kg)
Compatible Display(s)	Almost any VESA compliant monitor up to 24" VESA FDMI, MIS-D, 75/100, C (hole patterns = 100 x 100 mm and 75 x 75 mm)

- ⑧ Clean, concealed and neat routing of cables through the expansive cable management system



- ⑨ Extends/retracts LCD and keyboard up to 39" (99 cm); fold equipment back out of the way when not in use. With the keyboard folded up, total system depth is as little as 12" (30.5 cm)



Product Name	StyleView HD Combo System
Part Numbers	45-216-216 (white) 45-216-200 (black)
Product Name	StyleView HD Extender
Part Numbers	45-219-216 (white) 45-219-200 (black)

© 2009 Ergotron, Inc. rev. 10/15/2009 870-05-089-EA Content is subject to change without notification

**Americas Sales and Corporate Headquarters**

St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
sales@ergotron.com

**EMEA Sales**

Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com

**APAC Sales**

Tokyo, Japan  
www.ergotron.com  
apaccustomerservice@ergotron.com

**Worldwide OEM Sales**

www.ergotron.com  
info.oem@ergotron.com

